

Scottish Slate Gift - Slate Post Instructions

Supplied with your slate sign will be 2 x slate posts , 4 x Threaded Plastic Pins , 4 x m6 nuts and 2 part Epoxy Resin.

STEP ONE

Before using the resin have a dry run to make sure the slate posts match up to the corresponding holes in the back of the sign , the angled part of the posts should be on the inside with the longest side on the outside.

STEP TWO

After being comfortable with the layout carefully mix the 2 part resin together only using enough for each hole at a time (as the cure time is very quick) and fill the hole on the back of the sign 2/3rds full. Now place the plastic pin in the hole making sure you straighten the plastic pin, wipe any excess glue away from the hole while it's wet ,now repeat for the next 3 holes. Once complete leave overnight making sure the glue is well set. ON HOW TO USE THE RESIN PLEASE FOLLOW THE MANUFACTURER INSTRUCTIONS.

STEP THREE

Mark the position in your garden where you want to place your posts , please remember to make sure the ground is suitable for your sign. If the ground is to hard you may need to dig the soil first before installing failure to do this will damage the sign and posts.

STEP FOUR

Once the resin is set attach the posts remembering to line up properly then using the m6 nuts secure the posts making sure not to over tighten.

STEP FIVE

Now with gentle force push the sign and posts into the prepared ground far

enough to hold the sign in place

Now Stand Back And Admire